

Lifting Procedures for 35D and 45D Quad (4 Stage masts) with Hi-Vis IHR

Description:

This Technical Bulletin describes the proper method to lift a Lift Technologies 35D and 45D Quad Mast with Hi-Vis IHR.

Conditions:

If Lift Technologies 35D and 45D Quad Masts with Hi-Vis IHR are lifted improperly, the IHR bracket mounted to the Upper Intermediate Inner Crossmember can be damaged or moved out of position by the lifting mechanism.

Procedure:

To lift a Lift Technologies 35D and 45D Quad Masts with Hi-Vis IHR, use a strap wrapped through the mast with the strap installed to the left of the Upper Intermediate Inner IHR Bracket (See Photo). Do not wrap the strap around the bottom of the bracket.

